

# Maintenance Manual DG-1000M

## 0 General

### 0.1 Manual amendments

No.	Page	Description	Date
1	0.0, 0.1, 0.3 ÷ 0.7, 0.9, 0.12 ÷ 0.14, 1.2, 1.5, 1.8 ÷ 1.12, 1.20, 1.24, 1.31, 1.33, 1.34, 2.1 ÷ 2.4, 2.6, 3.1 ÷ 3.7, 4.6 ÷ 4.8, 4.11, 4.12, 4.19 ÷ 4.24, 4.26, 4.27, 4.29, 4.30, 6.1, 6.4, 7.2, 8.1 ÷ 8.4, diagrams 2, 3, 7, 15, 16, 23, add drawing W59, 10E202 issue C (only with coolant pump Pierburg)	Manual revision Alternative for coolant pump TN1000/22	October 2012
2	0.1, 0.3, 0.6, 0.11, 0.13, 0.14, 1.3, 1.4, 1.10, 8.2, 8.3, 8.5	Manual revision TN1000/23	July 2014
3	0.1, 0.3- 0.6, 1.11, 1.28, 3.8, 4.12, 8.2, 8.3, diagram 16	Fuel pressure regulator Manual revision TN1000/27	July 2015
4	0.1, 0.4 ÷ 0.7, 3.7, 4.25, 7.1, 7.2, 8.3, diagram 2, 10E202, Inspection instruction No. 1 for TN1000/30	Inspections drive mount Manual revision TN1000/30	March 2016

## Maintenance Manual DG-1000M

### List of effective pages (cont.)

Section	page	issued	replaced	replaced	replaced
	1.24	October 2010	October 2012		
	1.25	"			
	1.26	"			
	1.27	"			
	1.28	"	July 2015		
	1.29	October 2010			
	1.30	"			
	1.31	"	October 2012		
	1.32	"			
	1.33	"	October 2012		
	1.34	"	October 2012		
	1.35	"			
2	2.1	October 2010	October 2012		
	2.2	"	October 2012		
	2.3	"	October 2012		
	2.4	"	October 2012		
	2.5	"			
	2.6	"	October 2012		
3	3.1	October 2010	October 2012		
	3.2	"	October 2012		
	3.3	"	October 2012		
	3.4	"	October 2012		
	3.5	"	October 2012		
	3.6	"	October 2012		
	3.7	"	October 2012	March 2016	
	3.8	"	July 2015		

## Maintenance Manual DG-1000M

### List of effective pages (cont.)

Section	page	issued	replaced	replaced	replaced
4	4.1	October 2010			
	4.2	"			
	4.3	"			
	4.4	"			
	4.5	"			
	4.6	"	October 2012		
	4.7	"	October 2012		
	4.8	"	October 2012		
	4.9	"			
	4.10	"			
	4.11	"	October 2012		
	4.12	"	October 2012	July 2015	
	4.13	"			
	4.14	"			
	4.15	"			
	4.16	"			
	4.17	"			
	4.18	"			
	4.19	"	October 2012		
	4.20	"	October 2012		
	4.21	"	October 2012		
	4.22	"	October 2012		
	4.23	"	October 2012		
	4.24	"	October 2012		
	4.25	"	March 2016		
	4.26	"	October 2012		
	4.27	"	October 2012		
	4.28	"			
	4.29	"	October 2012		
	4.30	"	October 2012		
	4.31	"			
	4.32	"			
	4.33	"			
	4.34	"			
5	5.1	October 2010			
	5.2	"			
6	6.1	October 010	October 2012		
	6.2	"	October 2012		
	6.3	"			
	6.4	"	October 2012		

## Maintenance Manual DG-1000M

### List of effective pages (cont.)

Section	page	issued	replaced	replaced	replaced
7	7.1	October 2010	March 2016		
	7.2	October 2012	March 2016		
8	8.1	October 2010	October 2012		
	8.2	"	October 2012	July 2014	July 2015
	8.3	"	October 2012	July 2014	July 2015
		March 2016			
	8.4	"	October 2012		
	8.5	July 2014			
9	9.1	October 2010			
	9.2	"			
	9.3	"			
	9.4	"			
	9.5	"			
	9.6	"			
<b>Diagram</b>		issued	replaced	replaced	replaced
1	October 10				
2	October 10	October 2012	March 2016		
3	June 05	October 2012			
4	Nov. 01				
5	October 10				
6	October 10				
7	October 10	October 2012			
8	October 10				
9	October 10				
10	October 10				
11	October 10				
12	October 10				
13	October 10				
14	October 10				
15	October 10	October 2012			
16	October 10	October 2012	July 2015		
17	October 10				
18	October 10				
19	October 10				
20	October 10				
21	October 10				
22	October 10				
23	October 10	October 2012			
24	October 10				
25	October 10				
26	October 10				
27	October 10				

## Maintenance Manual DG-1000M

### List of effective pages (cont.)


<b>Enclosures</b>		issued	replaced	replaced
5EP31	Installation plan Dräger oxygen system	5.02.90		
10E4	Wiring plan electrically operated main landing gear	28.09.10		
10E202	Wiring plan DINA1 (in aircraft log)	29.07.10	28.09.12 issue C With coolant pump Pierburg	22.01.15 issue G with fuel pressure regulator Bosch
5V18	Tool for airbrake adjustment	14.10.94		
W51	Hook spanner for upper drive belt pulley bearings	20.11.96		
W59	Test adapter	18.06.02		
W66	Tool to check drive belt tension	17.09.10		
Z181	Installation of aerial for transponder in vertical fin DG-1000	18.04.08		
Z193	406 MHZ ELT antenna BD3 installation 2-seaters	4.11.09		
SI 67/07	Service Info Ballast box in the fin / foam rubber rings	5.11.2007		
/	Inspection instruction No. 1 for TN1000/30	March 2016		

## Maintenance Manual DG-1000M

- 16) Check and grease the starter motor gear shaft (don't grease the starter motor gear) Check starter motor for tight mounting. There should be no excessive radial free play of the starter motor gear axle. With too much free play the starter must be exchanged.
  - 17) Clean the starter ring gear and check for damage.
  - 18) Remove the fairings which protect the drive belts. Check the drive belts for wear. If a drive belt shows signs of wear all drive belts must be replaced. Check and correct tension (see sect. 4.10.2).  
Check if drive belt operating time is exceeded see section 0.4.  
Check the rollers which guide the drive belts for tight fit to their mounting brackets and for easy turning. If there is any significant friction in their bearings, the rollers have to be replaced.  
Check the complete drive mount for cracks according to Inspection instruction No. 1 for TN1000/30.  
Re-install the drive belt fairings, secure screws with Loctite 243.
  - 19) Clean the spindle drive. Check the connections of the spindle drive to fuselage and powerplant.
  - 20) Check the time taken to retract and to extend the power plant. If it takes longer than described under sect. 1.13.2 the gas strut has to be replaced.
  - 21) Check the engine retaining cable for wear and kinks.  
Check the engine position with the retaining cable fully tensioned according to sect. 1.13.3. If the cable is too long it has to be adjusted at the adjustment screw in the rear end of the engine bay.
  - 22) Check the main bearings of the upper pulley for any free play.
  - 23) Check the tension of the propeller bolts: remove the lockwire, loosen the propeller bolts and retorque them with a torque wrench, torque value see section 1.12.9. Secure again with lockwire according to section 4.10.6.
  - 24) Check the propeller blades for any damage.
  - 25) Check all electric cables and connectors. Check the terminals especially of the starter positive and earth wire for cracks.
- Note:** The critical spots may be covered by heat shrink tubing.
- 26) Check the whole electrical system wiring, ensure all equipment is secure and all connections are OK. Check proper functioning of all systems and fuses/circuit breakers.
  - 27) Reinstall the engine bay doors. Check all the hinges on the engine compartment doors for proper fit and any cracks, tears etc. Check if hinge pins are secured properly.  
Check the engine door control system.

### 4.10.6 Securing the propeller bolts and the bolts of the rear engine mount

1. Use lockwire with min. 0.8 mm (0.03 in.) diameter.
2. Secure the propeller bolts as follows:
  - a) Slide the wire through the hole in the bolthead and bend it around the head. The wire should run tangential to the bolthead so that it secures the bolt clockwise to tighten it. Direct the end of the wire which was laid around the head underneath the wire which runs through the hole.
  - b) Twist both ends of the wire clockwise up to the other bolthead. Slide the upper wire through the hole in the bolthead and bend the other wire around the head. Twist with max. 8 rotations per inch.
  - c) Direct the end of the wire which was laid around the head underneath the wire which runs through the hole. Twist the ends anticlockwise min. 3 max. 8 rotation. Cut off the surplus and bend the end to prevent injuries.



**Caution.** Don't damage the lock wire. Also minor scratches or removal of the galvanisation have to be considered as damage.

## Maintenance Manual DG-1000M

### 7 List of special tools etc.

- A Special tool with 6 mm thread (W38/2) to operate the tailplane locking pin and for the locking pins of the rear wing suspension.
- B Special tool W36 (or a suitable pin with 6mm diameter) for derigging of the outboard wings and for the cover plate of the ballast box in the fin.
- C Tool for airbrake adjustment: 5V17 and rod according to drawing 5V18.
- D Open-end wrenches


1/4" = 6,35 mm	SW 12	SW 19
SW 7	SW 13	SW 22
SW 8	SW 14	
SW 9	SW 17	
SW 10	11/16" = 18 mm	

- E 22 mm socket and ratchet (for tensioning the drive belts)
- F Allen key wrench  
3 mm, 4 mm, 5 mm, 6 mm, 7 mm, 8 mm, 10 mm and 12 mm
- G Wrenches for slotted nuts (hook spanner) according to drawing W51 (encl.) (for the bearings of the upper drive belt pulley)
- H Spring balance max. reading 50 N (11 lbs.) (to determine control surface moments)
- I Spring balance max. reading 100 N (22 lbs.) (to determine the over-centre locking moment of the airbrakes)
- J Nicopress tool 64 – CGMP (to produce cable connections)
- K For filling the wing ballast tanks (Option): Hose with outside dia. 25 mm (1 in.), 1 m (3.2 ft.) long.
- L Refuelling hose for fuselage fuel tank Z155/2
- M Torque wrench Torque range 0 - 150 Nm (0 - 110 ft lb) with socket wrench 19 mm (for assembly of the drive belt pulley and the magneto housing of the generator)
- N Torque wrench range 0 - 50 Nm (0 - 370 ft lb) with socket wrenches 10, 13, 17, 19 mm and 21 mm (13/16 in.) for sparkplugs and Allen key inserts 3, 4, 5, 10 mm
- O Wrench for spark plugs 21 mm (13/16 in.)
- P Spring balance max. reading 200 N (44 lbs.) for measuring belt tension
- Q Crimp tool for clamps XO for 6mm bungee (bungee for retaining cable)
- R Crimp tool for hose clamps OETIKER 14100083 (especially at the coolant hoses)
- S Manometer 0 - 6 bar fuel resistant with hose 3 m long and hose connector GES8/M10x1 (to measure the fuel pressure during the 25h inspection)



## Maintenance Manual DG-1000M

- T Hose connector GES8/M10x1 with hose 2 m long (for emptying the cooling system)
- U Solo engine tool set incl. puller assembly for lower drive belt pulley incl. flange bolt and puller assembly for magneto housing
- V Shortened Allen key wrench see sketch (for removing the lower bolts of the exhaust manifold)




## Maintenance Manual DG-1000M


- 60507526 Fuel hose 15 x 23 mm fabric braided (at fuel pump)
- 30092051 Metal braiding inner dia. 8 mm
- 60000377 Copper sealing ring 10x14x0,8 DIN 7603 A for service port

### 8.1.2.4 Parts for the electrical system


- 60510899 Main battery: Odyssey PC625 12V/17Ah
  - 41076003 DEI-NT- DG-1000M
  - 41076004 DEI-NT-DG-1000M second unit (rear cockpit)
  - 41076005 Control unit-NT-DG-1000M
  - 41076006 Engine control unit ECU Trijekt-Plus T101 Solo No. 23 00 886
  - 41076007 Controller for emergency system Solo No. 23 00 896
  - 41075210 Engine speed sensor (normal system+emergency system) Bosch 0261210147 assembled with wiring and plugs
  - 60510836 Throttle valve sensor: Bosch 0 280 122 201
  - 60510837 Probe for coolant temperature Bosch 0 281 002 209
  - 60510669 Intake air sensor Epcos B57881S212F
  - 41075204 Proximity switch ready assembled with wiring and plug
  - 41075211 Voltage converter 10E211 for coolant pump Pierburg
  - 60510834 Ignition coil Solo No. 23 00 883
  - 60510832 Regulator Ducati 34407011
  - 60504044 Voltage reducing module for generator/regulator
  - 60510202 Condensor for generator/regulator 100.000µF/40V
  - 60510464 Limit-switch engine retracted and engine extended 164-574, alternatively SI2010-B2T20YR30,5m
  - 60510506 Manual extension-retraction switch MTG 106 G
  - 60510465 Black cap for switch MTG206S
  - 60510483 Switch for emergency engine control: APEM 5636 MA
  - 60510466 Red cap for APEM 5636 MA
  - 60510859 Key switch 3 Pos, 2 Pol KL09-1908KA with wiring (Master switch)
  - 60510362 Switch STA 106 E (selector intern-extern)
  - 60510372 Press-button DJET 07.17502.21 for starter
  - 60510375 Press-button 12G2904 for refuelling pump
  - 60510385 Circuit breaker ETA 2A
  - 60510386 Circuit breaker ETA 3A
  - 60510437 Fuse 01191017003 80 A for battery
  - 60510796 Socket BSB 12 (in main bulkhead)
  - 60510797 Plug BSK12 for socket BSB 12
- From ser. No. 10-225 on:**
- 60510880 Socket XLR 3-pole NC3FD-LX-BAG
  - 60510881 Plug XLR 3-pole NC3MX-BAG (for socket XLR



**Ansicht/view X**





Seitensteuerung  
rudder control




Schlüsselring Ø 20mm  
key ring dia. 20mm  
Gummiseil Ø 2 L=410mm  
rubber cord dia. 2mm length 410mm  
Ringschraube/eye bolt  
M6-PH 370630

**Detail A**



Anschlag siehe Ansicht X  
stop see view X

siehe Diagramm 10  
see diagram 10  
Detail Z



siehe Detail A  
see detail A

Diagramm 2  
diagram 2


Ausgabe: März 2016 TM1000/30  
issued: March 2016 TN1000/30



**DG Flugzeugbau GmbH Inspection instruction No. 1 for TN1000/30  
DG-1000M drive mount**


**A. Checks according to TN1000/23. These checks must only be performed in case TN1000/23 instruction 2 (installation of stiffeners) has not been performed so far. Check during each daily inspection and during the 25 h inspection.**

1. Extend the powerplant. Use a powerful torch to look at the left hand side to find the area shown in the picture below. Check for any cracks. Touch this area also with your fingers to find a crack.
2. It is nearly impossible to look and touch the right hand side with the engine extended, so retract the engine and stop before the engine doors close. Check the front (now upper side) of the left hand tube again and check also the right hand side. Touch around the tube with your fingers to find any crack on the lower side.
3. In case you find cracks don't operate the engine any more.



**B. Checks for cracks at other areas of the drive mount. Check during each daily inspection and during the 25 h inspection.**

1. Extend the power plant half-way, so that the front of the drive mount is completely visible.
2. Check the complete drive mount for cracks.  
Especially check the right main tube in the area between the cross beams of the spindle drive and the cross tube of the lower radiator suspension for cracks, both the front as well as the rear parts. The area around the upper cross tube is partly covered by the drive belt cover. Checks of this area see C.
3. Then check the left main tube between the two cross bars for cracks.
4. In case you find cracks don't operate the engine any more.



**C. Checks for cracks in the areas of the drive mount covered by the drive belt fairings. Check every 5 engine hours and during the 25 h inspection.**

1. In addition to the checks see B remove the drive belt fairings and check all areas visible now.
2. Re-install drive belt fairings. Secure screws with Loctite 243.

**Caution:** In case cracks are found according to TN1000/30 the drive mount must be exchanged against a mount of the new design prior to next engine use.