

Manual amendments

No.	Page	Description	Datem
1	2, 3, 4, 25, 28, 49, 86, 91, 93, 8E101, 8E105	Manual revision TN 873/27	Nov. 2001
2	1 - 5, 43, 44, 47, 92, diagram 11	Fuel hoses TN 800/44	October 2016
3	1-6, 33,34, 44, 93, diagrams 3, 9	manual revision, coolant hoses TN800/45	July 2017

Instructions for continued airworthiness
Maintenance manual DG-800 B MW

Content	Page	approved
0	Airworthiness limitations	5 July 17
		6 July 17
1.	System description and adjustment data	issued
1.1	Wing and tailgroup setting data	7 Nov. 96
1.2	Elevator control and trim system	8 " "
9	" "	
1.3	Rudder control	10 " "
1.4	Aileron and wing flaps control	11 " "
12	" "	
1.5	Airbrake control and wheel brake	13 " "
1.6	Undercarriage	14 " "
1.7	Tow hooks	15 " "
1.8	Waterballast system	15 " "
1.9	Massbalance and weights of control surface	16 " "
1.10	Fore and aft play of the wings	17 " "
1.11	Power plant	18 April 96
		19 " "
		20 " "
1.12	Retraction-extension mechanism	21 " "
		22 " "
1.13	Fuel system	23 " "
		24 " "
		25 Nov. 01
		26 April 96
1.14	Electrical system	27 " "
		28 Nov. 01
		29 April 96
		30 " "
		31 " "
		32 " "
2.	Inspections	
2.1	Daily inspection	33 July 17
2.2	Regular inspections	33 " "
		34 July 17
2.3	Inspection after a heavy landing	35 Nov. 96
		36 " "
		37 " "
2.4	Inspection procedure for increase of service time	38 " "
		39 " "
2.5	Inspection procedures	39 " "

Instructions for continued airworthiness
Maintenance manual DG-800B MW

Content	Page	issued
3. Maintenance		
3.1 General maintenance	40	Nov. 96
3.2 Maintenance of the airframe	41	" "
3.3 Greasing programme	41	" "
3.4 Damage of the airframe	42	" "
3.5 Maintenance of the powerplant	43	October 16
" " " "	44	July 17
" " " "	45	April 96
" " " "	46	April 96
" " " "	47	October 16
4. Detailed instructions for assembly and servicing work		
4.1 Replacement of the water ballast bags and servicing of the valves	48	Nov. 96
4.2 Replacement of control cables	49	Nov. 01
4.3 Adjustment and servicing of the control circuit	49	" "
4.4 Removal and installation of the undercarriage	50	Nov. 96
4.5 Fixing excessive free play of the canopy	51	" "
4.6 Removal a. installation of the flaperons	52	" "
4.7 Working instructions for heat-shrink tubing	53	" "
4.8 Securing with Loctite 72 b	53	" "
4.9 Controlsurface seals and turbulators	54	" "
" " " " " "	55	" "
4.10 Exchange of the wing fuel tanks	56	" "
4.11 Mounting a. tensioning of the drive belt	57	" "
" " " " " "	58	" "
4.12 Replacing the bearings of the propeller shaft	59	" "
" " " " " "	60	" "
4.13 Replacement of the engine extension gas-strut	y61	" "
4.14 Replacement of the engine retaining cable	62	April 96
4.15 Filling and bleeding the cooling system	63	" "
4.16 Removal and installation of the engine	64	" "
" " " " " "	65	" "
" " " " " "	66	" "
" " " " " "	67	" "
" " " " " "	68	" "
4.17 Section not effective	(69)	
" " " " " "	(70)	
4.18 Securing the propeller bolts	71	Nov. 96
4.19 Checking the ignition unit	72	April 96
" " " " " "	73	" "
" " " " " "	74	" "

Instructions for continued airworthiness
Maintenance manual DG-800 B MW

Content	Page	issued
4.20 Section not effective	(75-77)	
4.21 Section not effective	(78)	
4.22 Calibration of the fuel display in the DEI	80 81	April 96 " "
4.23 Section not effective	(82)	
4.24 Determ. of the moments of the flaperons	83	Nov. 96
4.25 Internal sealings of control surfaces	84 (85)	" "
5. Weight and balance	86	Nov. 01
weighing	87	Nov. 96
6. Instruments and accessories list	88	" "
" " " "	89	April 96
7. List of special tools	90	" "
8. Partslist	91	Nov. 01
" " " "	92	October 16
" " " "	93	July 17
" " " "	94	Nov. 96
Diagrams		issued
1 Elevator control circuit, trim		Nov. 93
2 Rudder control circuit, landing gear		" "
3 Aileron, wing flap and spoiler control circuits, fuselage side		July 17
4 Flaperon and spoiler control circuits, wing side		Nov. 93 " "
5 Tow hooks, waterballast system		" "
6 Pitot static system		" "
7 Placards		April 96
8 Powerplant		" "
9 Cooling system		July 17
10a Extension-retraction mechanism type Stross		Nov. 96
10b Extension-retraction mechanism type Magnetic		" "
11 Fuel system		October 16
12 Tailwheel		Nov. 93
14 Engine doors and retaining cable		April 96
Enclosures		issued
Equipment list	95	Nov. 96
Checklists for maintenance work	96	" "
EFWK Installation landing gear doors		Oct. 87
6EP27M Installation Dräger oxygen system		28.08.90
8EP35 Installation wing fuel bags		12.10.93
8EP38 Installation ELT		07.08.96
8M110 Drawing Assembly upper drive belt pulley		20.03.96
8V96 Drawing		19.12.94
W 40 Drawing Puller assy. for lower pulley		04.02.95
W51 Drawing Hook spanner for bearings of upper drive belt pulley		20.11.96
8E101 Wiring scheme		12.11.01
8E102 Wiring plan DIN A 1 (in aircraft log)		09.01.96
8E105 Amendment to wiring plan 8E102 TN873/27		09.11.01

0. **Airworthiness limitations**

0.1 **Repairs**

Repair damaged wings, fuselage and tail surfaces prior to next flight. Follow the instructions of the DG-800 B repair manual. Repairs outside the scope of the DG-800 B repair manual and major repairs must be accomplished at a certified repair station or by a certified mechanic rated for composite aircraft structure work in accordance with DG repair methods.

0.2. **Life time of the airframe**

The maximum allowable operating time for composite sailplanes and motorgliders is 12000 flight hours. Therefore inspection according to sect. 2.4 of this manual has to be executed at 3000 h, 6000 h and every 1000 hours following thereafter.

0.3. **Life time of components**

a) The following components of the power plant have to be replaced after 400 engine hours.

1. All nuts and bolts on the engine
2. The bearings of the upper drive belt pulley

b) All **flexible fuel lines and the gasket of the drainer** have to be exchanged after 6 years.

TN 800/44: When instructions 2 and 3 of this TN have been accomplished the life time of the flexible fuel lines is 10 years.

c) The **hoses of the cooling system** have to be exchanged after 6 years.

Note: The **coolant** (type see section 1.11.2) **has** to be exchanged after 6 years.

d) The **drive belt** has to be exchanged after 50 engine hours.

e) The **spark plugs** have to be exchanged after 25 engine hours.

- f) The **fabric straps of the safety harness** have to be exchanged according to the instructions of the respective manufacturer. If no limitations are given, exchange after 12 years.
- g) **Flexible fuel bags in the wings (option)**
Type Uniroyal (rubber): these will have to be exchanged after 10 years.
Type HFK (plastic): see Mounting and testing instructions for HFK TLF.

Note: All **other components** like tow hook, wheels, gas struts, control system parts, bolts, pins etc. have no life time limitation, but should be replaced when worn, damaged or disqualified by excessive corrosion.

0.4 Service time, maintenance documents of equipment and components

Follow the instructions of the respective manufacturer:

- a) Operating Manual for Safety Tow Releases Series: Europa G 88 Safety Tow Release
latest approved version.

And if installed:

Operating Manual for Tow Releases Series: E 85 Nose Tow Release
latest approved version.

- b) Safety harness: instructions of the manufacturer latest approved version.
Approved types see section 6.3.
- c) Minimum instrumentation: instructions of the manufacturer.
Approved types see section 6.1, 6.2 and 6.4.
- d) Engine: Manual of the engine manufacturer latest approved version.
- e) Propeller: Technoflug Operation and maintenance manual No. P3 latest approved version.

0.5 Power plant trouble shooting

Please find a checklist in the DG-800B flight manual section 8.8.

2. Inspections

2.1 Daily inspection

see flight manual DG-800B section 4.3..

2.2 Regular inspections

A Annual inspection

- Execute all items of the daily inspection see flight manual section 4.3.
- Check the rudder cables for wear especially around the S tubes on the rudder pedals. Worn rudder cables should be replaced (see section 4.2.
- Check the sealing of the rudder (see section 4.9.5.
- Inspect all bolted connections and locking devices ie. locknuts, split pins etc.
- Check all metal parts for adequate greasing and rust prevention. (see section 3.3).
- Check the control surface deflections (see sections 1.2 up 1.4).
- Check the free play in all control circuits (see section 1.2 up to 1.6)
- Check the fore and aft play of the wings (see section 1.10).
- Check the canopy emergency releases according to section 7.15 of the flight manual.
- Check the tension of the lines of the waterbag attachment (see section 4.1.).
- Landing gear: Check if the bolted connection between actuating lever and rear upper fork is tightened?
- Check all accessible drain and ventilation holes if clogged, especially on the lower fuselage side.
- Check if the powerplant has been serviced according to section 3.5.1.
- Check the friction brake of the throttle control (see sect. 1.11.8).
Check the torque of the propeller bolts see sect. 3.5.1 item 26 of this manual.
- Tow hooks: The operating and maintenance instructions for the release mechanisms, see sect. 0.4 of this maintenance manual have to be followed.
- All-up weight and centre of gravity: These should be checked at least every 4 years during the annual inspection.

B) Special inspections

Tow hook:

After a wheel up landing, the tow hook mechanism is to be carefully checked for any damage.

After a landing where the fuselage nose has touched the ground, the nose tow hook (Option) is to be cleaned and to be checked for correct functioning.

C.G. weighing:

After all work which may influence the C.G., but at least every 4 years with the annual inspection.

C) Wing fuel bags, every 5 years

Check for external wear and execute pressure check with 0.15 bar (2.2 psi), tanks installed in the wings.

6. Check the function of the primer valve and nozzle (engine must be cold).
First disassemble the positive wire from the starter motor and insulate the wire. Remove the intake air filters.
Switch the primer switch in auto position.
Switch on DEI and ignition:
Press the starter button. The DEI must show P on the center display and fuel must be injected via the nozzles into the intake manifolds of the carburetors.
Test only for 2-3 seconds, otherwise you may flood the engine. Switch off the ignition.
Check the hoses which connect the primer valve to the carburetors for any damage.
7. Check all fuel lines for any wear, fissures, kinks, tight fit and leaks. For the check switch on the ignition to run the electric fuel pump to demonstrate operating fuel pressure.
8. Check the intake airfilters for excessive dirt and wear. Reinstall the filters.
- 8.a With the airfilter still removed check the screws of the throttle valve and of the choke valve (if existent) for tight fit.
9. Oil all cables and associated levers and check for proper functioning. Replace cables when worn. (see 1.11.8 and 1.11.9).
10. Clean engine and radiator
11. At the first 25 hr. check, tighten all cylinder head nuts with 2.2 daN m (16 ft.lb.).
12. Check cooling system for leaks, refill coolant if necessary, check antifreeze.
Check the radiator and its mounting.
Check the coolant hoses.
To check the water pump, switch on the ignition.
You should hear a buzz.
13. a) Remove the exhaust manifold.
b) Check the cylinders and pistons via the exhaust ports for seizing marks, for carbon remains and for sticking piston rings. Illuminate the combustion chamber and check for combustion deposits. Use a torch and mirror for these checks. If seizing marks are detected the engine must not be used.
Excessive combustion deposits have to be removed. With sticking piston rings the cylinders must be removed. Take out the piston rings and clean the grooves and the rings or replace the rings. Remove also any combustion deposits inside the pistons.
Caution: Necessary repair work must be accomplished at a certified repair station rated for such engine work.

8.2 **Parts for the electrical system**

60510891 Battery HDS 6120 6V 12Ah equipped with
screw - terminals

40876050 DEI MC801

40876030 Control unit 8E103 (including relays and
regulator)

60510555 Ignition electronic boxes IGN 0295

60510440 Fuse 5 x 20 0.2A mt for ``

60510556 Ignition coil SEM 10079000 P17

60510463 Limit-switch engine retracted 164-56401
modified by soldering a plate to the
actuator

60510464 Limit-switch engine extended and propeller
aligning position 164-503

60510476 Manual extension-retraction switch
APR 20-647H

60510475 Switch to switch over from normal to
emergency extension-retraction
APR 20-646H

60510813 Master switch Bosch 0341001001

60510812 Key for master switch Bosch 0341001001

60510478 Engine master switch 631 H/2 15A

60510370 Starter button SECME 07 17801 21

60510392 Circuit breaker Klixon 7277-2-10A
for spindledrive Magnetic GST 2011

60510391 Circuit breaker Klixon 7277-2-15A
for spindledrive Stross ELT 10

60510385 Circuit breaker ETA 2A

60510386 Circuit breaker ETA 3A

60510387 Circuit breaker ETA 4A

60510384 Circuit breaker ETA 5A


60510388 Circuit breaker ETA 10A

60510436 Fuse 535257 60 A for batteries

60510550 Proximity switch Insor INCT 1212

60510796 Socket BSB 12 (in main bulkhead)

60510785 plug BSK12 for socket BSB 12



Kühlwassersystem DG - 800 B (cooling system)

Diagramm 9

Wasserschläuche
water hoses

Schläuche hergestellt aus 2 Stück Artikel Nr. 60504053
 coolant hoses made from 2 pieces Artikel Nr. (part No. 60504053)

Metallgeflecht ϕ 6 mm innen
 metal fabric shield inside dia. 6 mm

250 Länge
 length mm

