

1. Remove side panels from the left side of the forward and rear cockpit.
2. Replace airbrake pushrod (Part 5St69) in the forward cockpit with pushrod with additional handle (Part 5St69/2), see also maintenance manual, diagram 3. Use new M6DIN985-8 zn self-locking nut and 1,5x12 DIN94 split pin.
3. Extend airbrakes completely, measure offset X between the stop 5St82/2 and 5St82/3 according to diagram 3 in maintenance manual.
4. Mark the position of the additional handle on the front side panel. Also mark the offset X and an additional 5 mm rearward from this position. The panel should be cut as in the photo below from this point.
5. Press S80 handgrips on both handles.
6. Reinstall forward and rear panels in the cockpit.

