

Maintenance Manual DG-1000T

No.	Page	Description	Date
12	0.2 ÷ 0.9, 0.9a, 0.10 ÷ 0.12, 1.2, 1.5, 1.11, 1.14, 1.15, 1.27 ÷ 1.29, 1.33, 2.1, 2.4 ÷ 2.6, 3.3, 4.8, 5.1, 6.1, 6.2, 6.4, 8.3, 9.2, diagr. 1, 9, 11, encl. 4 pages 1, 2, 2a, 3, Z193, SI 67-07, remove 5EP50	Manual revision TN1000/18	February 2011
13	0.6, diagrams 8 and 9	Wheel brake TN1000/21	July 2011

Maintenance Manual DG-1000T

0.2 List of effective pages (continued)

diagram	issued	replaced/	replaced/	replaced/
1	May 2004	Oct. 2010		
2	Nov. 2001			
3	June 2005			
4	Nov. 2001			
5	Nov. 2001	January 2007		
6	Nov. 2001	January 2007	March 2008	Not valid for 10-101, and from 10-128 on
6a	March 2008			
7	Nov. 2004			
7a	Oct. 2008			
8	Nov. 2001	January 2007	July 2011	
9	June 2005	January 2007	Febr. 2011	July 2011
10	May. 2005	January 2007		
11	June 2005	Febr. 2011		
12	Sept. 2003	January 2007		
13	June 2005			
14	June 2005	October 2007		
15	June 2005	January 2007		
15a	Oct. 2006	Dec. 2006	January 2007	
16	June 2005	May 2008		
17	Febr. 2008			
18	Febr. 2008			
19	March 2008			
20	Nov. 2008			
21	Nov. 2008	Oct. 2010		
22	Nov. 2008			
5EP34	25.01.90			
5V18	14.10.94			
10FW2	05.10.99			
10E4	20.10.08			
10E4 issue E	8.10.10			
10E102	14.09.05	5.12.05	26.01.06	
10E103	24.06.05			
Encl. 1	June 2005			
Encl. 2	June 2005	Page 1 January 2007	Pages 2, 3 May 2008	
Encl. 3	March 2008			
Encl. 4	Nov. 2008	Page 2, 2a , 7 Oct. 2010	1, 2, 2a, 3 Febr. 2011	
SI 67-07	5.11.2007			
Z193	4.11.2009			

Diagramm / diagram 8

Fahrwerk, hydraulische Radbremse / Landing gear, hydraulic wheelbrake



