ual
contents
and
amendments

	January 2001	Installation of a parking brake combined with an airbrake securing device (Piggott-hook) (TN323/12)	Flight-m. 14	11
	1998	ow hook	1, 17, 27	
	April	(TN 323/9) Installation of an	Plight-m.	10
	e198	Marking of canopy emergency release and ventilation (TN 323/6)	t-m. 7/12, 13a m. . 3a	ω
	Febr. 85	Technichal Note No. 323/5	Manual p.3, 27, 28 Maintm. p.0, 7, 7a, 7b, 10, 13	7
	Sept. 80 Sept. 80	Waterballastsystem	Manual p.22 Maintm. p.7	9
	Sept. 80	Spring mounted landing gear	Maintm., diagr.7	Л
	Sept80	Single piece canopy	nual p.	4
	sept. 80 sept. 80 sept. 80	Automatic trimm control and wheel brake control connected to the airbrake handle	Manual. P.13, 14 Maintm. Cover, p.6, 7, 18	ω
	Sept. 80 Sept. 80 Sept. 80	Automatic self connection for the elevator control	Manual p.22 Maintm. p.18 diagr. 6	Ы
	June 80	Main pin securing	Manual p.22	1
Signat	Date	Description	Page	No.

Issued: January 2001

 \vdash

DG-200 Manual

<u>Trim:</u> Automatic trim control

and to place the control stick in the desired position. To adjust the trim you have to pull the small release handle at the control stick

control stick position. When you let go the release handle your aircraft is trimmed to the adjustet

securing device (Piggott-hook): Airbrake handle/ Optional parking brake combined with an airbrake

Airbrake handle - blue

The wheel brake is operated at the end of the airbrake handle travel

Optional parking brake combined with an airbrake securing device (Piggott-

this position. the cockpit wall. A detent will engage in one of 4 notches to hold the system in Pull the airbrake handle back to actuate the wheelbrake and push the handle to

4 notches to avoid inadvertent deployment of the airbrakes. To open and to close the detent passes the notches. the airbrakes the operating handle must be rotated into the cockpit so far, that In case the airbrakes mistakenly haven't been locked, a detent engages in one of

Manual contents and amendments

y brake 2001 ed with an ce securing (Piggott- (TN 323/12)
a January
E an April hook 1998
Oct.
canopy June
No. Febr.
Waterballastsystem Sept. Sept.
Sept
canopy Sept.
the dle
brake control Sept.
the Sept.
securing June
Date

Issued January 2001

17/1

DG-200/17 C Manual

Manual contents and amendments

	2001	parking brake combined with an airbrake securing device (Piggott-hook) (TN 323/12)	. T T A 711 C - III.	F
	1998	ow hook	, 27	- C
	Oct. 1996) h	Maintm. p.0,	100
	June1986	Marking of canopy emergency release and ventilation (TN 323/6)	Flight-m. p.12, 17/12, 12a, 13a Maintm. diagr. 3a	ω
	Febr. 85	Technichal Note No. 323/5	Manual p.3, 27, 28 Maintm. p.0, 7,7a,7b,10,13	7
	Sept. 80	Waterballast system	Manual p.22 Maintm. p.7	٥
	Sept. 80	Spring mounted landing gear	Maintm., diagr.7	Л
	Sept80	Single piece canopy	Manual p.13a	4
			,	
	Sept. 80	Automatic trimm control and wheel brake control	Manual. P.13, 14 Maintm.	ω
	Sept. 80 Sept. 80 Sept. 80	Automatic self connection for the elevator control	Manual p.22 Maintm. p.18 diagr. 6	N
	June 80	Main pin securing	Manual p.22	1
Signat	Date	Description	Page	No.

Issued January 2001

17C1