Subject: Concerning: Flight-maintenance and repair manual DG-400 Serial No. 4-1 up to 4-200

Accomplish-

ment: Reason: Measures: within 30 days Manual revisions

Exchange or ammend the enclosed manual pages new issue Febr. 1987. The new passages are marked and to be studied carefully.

Concerning	pag	е	
Flight manual content (replaces special US page)	1		
content (replaces special US page)	2 2a		
content (replaces special US page) fuses, landing gear operating	2a 9		
emergency switch	11		
fuel gauge calibration device	15		
min. equipment cloud flying	17 19	•	
max. RPM (transient) starting the engine-starter not working			
emergency switch	26		
check circuit breaker - propeller 28,			
engine extension-control light	31 35		
green control light Spin recovery	40		
Rigging - hotellier quick connects	45		
Rigging - stabilizer	46 47		
Filling the water ballast tanks Parking	47		
Service and care	50		
Service and care	50	a	
Max. range Maintenance manual	59		
content	1	(1	US)
content	2		US)
System description-general	3	а	
(replaces special US page 3 a)	4	-	
angles of inciduce Undercarriage-lock, tailwheel	11		
Towhook	12		
Engine - idle adjustment	13		
Tightening torques Retraction - extension mechanism	14 15		
Socket - connection of terminals	19		
DEI - fuel gauge	20		
Switches and relays	21		
Wiring Inspection - towhook - propeller	22 26		
Inspection - towhook - propeller	26	a	
General maintenance	30		
Greasing Check wining terminals	31		
Check-wiring terminals Check-tension of propeller bolts	32 33 34		
Removal of power plant	34		

## Glaser-Dirks Flugzeugbau GmbH Im Schollengarten 19-20, 7520 Bruchsal 4 Telefon 07257-1071 Telex 7822410 GLDG LBA anerkannter Herstellungsbetrieb IB 25 LBA anerkannter Luftfahrtlechnischer Betrieb IIA 279

Technical Note 826/17 Page 2 of 2

Concern Disconn	_	.ng v	iring	from	spi	ndle	page 39
drive Removal motor Removal					retr	eaction	40 41 42 43 44
Access			donhoo	dnut	<b>-</b>		46 b
Fixing						,	46 c
the can		:02T /	e iree	: рта	y 01		40 6
Working		etpu	itione	for	chri	nking	46 d
hose	T 11 c	ou u	CTOHS	101	5111 1	.IIKIIIB	40 u
Instruc	tior	ı for	secur	ing	the	propeller	46 e
bolts							•
New ins		nents	3				49
11	11						50
elevato			ol			diagram	1
landing		ar				11	2 2 a 3
tailwhe						††	2 a
aileron			L			11	3
Repair							•
Content	(re	eplad	es spe	ecial	US	page)	4/2
Foam							4/6
11							4/7

Note:

This measure may be executed by the owner himself and is to be entered in the aircraft logs mentioning TN 826/17

Author

Bruchsal 4 09.03.1987

Wilhelm Ox Dipl.-Ing. W. Dirks

El. Selile

Type certification inspector

The German original of this TN has been approved by the LBA under the date of April 8 1987 and is signed by Mr. Skov. The translation into English has been done by best knowledge and judgement. In any case of doubt the German original is authorita-

LBA-approved:

tive.