### **0** MANUAL CONTENTS

#### 0.1 Log of Revisions

Any revision of the present manual, except actual weighing data, must be recorded in the following table and in case of approved Sections endorsed by the responsible airworthiness authority.

The new or amended text in the revised page will be indicated by a black vertical line on the right margin, and the revision No. and the date will be shown on the bottom left hand of the page

Rev.	Pages affected	Description	Date	EASA
no.				Approval
1	0-1,0-2,0-3, 0-4, 0-5,	TN8019, wheel brake	Feb. 2011	13.10.11
	4-15, 4-27, 4-28, 4-32,	actuated by airbrake handle		
	7-2, 7-3			
2	Title page, 0-1 ÷ 0.3, 0-	ÄM LS8-1, Miscellaneous	Dezember	14.02.12
	5, 4-4, 4-9, 7-2, 7-3, 7-	improvements from	2011	
	5, 7-13a, 7-14	ser. No. 8527 on		
3	0-1, 0-3, 0-5, 4-8, 7-6	TN8021 small tailwheel	January	24.02.
			2015	2015
4	0-1, 0-5, 9-5	TN DG-G-11 NOAH	May2015	7.07.
		Improvements		2015
5	0-1, 0-2, 0-3, 0-5, 1-4,	TN 8024 Manual revision	June 2016	5.08.
	2-12, 4-24, 7-14			2016
6	0-1, 0-3, 4-6	TN8023	December	Feb. 1 <sup>st</sup> ,
		15m Dillinger Winglets	2016	2017

#### Contents

## **<u>0.2 List of Effective Pages</u>** continued

Chapter	Page	Edition	Edition	Edition	Edition
3	3-1	April 2005			
	3-2	April 2005			
	3-3	April 2005			
	3-4	April 2005			
	3-5	April 2005			
	3-6	April 2005			
	3-7	April 2005			
	3-8	April 2005			
	3-9	April 2005			
	3-10	April 2005			
	3-11	April 2005			
	3-12	April 2005			
	3-13	April 2005			
	4-1	April 2005			
	4-1 4-2	April 2005 April 2005			
	4-3	April 2005 April 2005			
	4-4	April 2005 April 2005	Dec. 2011		
	4-5	April 2005	Dec. 2011		
	4-6	April 2005 April 2005	Dec. 2016		
	4-7	April 2005	2010		
	4-8	April 2005	Jan. 2015		
	4-9	April 2005	Dec. 2011		
	4-10	April 2005	20002011		
	4-11	April 2005			
	4-12	April 2005	June 2016		
	4-13	April 2005			
	4-14	April 2005			
	4-15	April 2005	Feb. 2011		
	4-16	April 2005			
	4-17	April 2005			
	4-18	April 2005			
	4-19	April 2005			
	4-20	April 2005			
		-			

### **4.2 RIGGING AND DE-RIGGING** (continued)

#### 4.2.1 INSTALLATION OF 15 M <49 FT> OR 18 M <59 FT> WINGLETS

- 1. Insert winglet until securing nut starts catching thread; when aileron pins of 18 m <59 ft> version are not correctly aligned, installation is impossible.
- 2. Turn nut in direction that it pulls winglet into position.
- 3. Lock nut until tip is free from play: zero play is reached, when force increases considerably during turning of nut with supplied key. Turn not further than next notch catching ratchet.
- 4. Tape wing tip intersection.

# IMPORTANT NOTE: Due to flutter considerations it is not allowed to mount additional masses (e.g. cameras) on the winglets!

#### 4.2.2 DE-RIGGING

- (1) Reverse **assembly** sequence.
- (2) 15m <49 ft> winglets may be stored in cockpit, when using some padding.
- (3) Air brake system should be unlocked to avoid permanent pressure on flexible covers and resulting possible deformations (overcenter in wing).

# <u>Warning</u>: With wings positioned vertical in trailers with hinged cover, the air brakes may open and be damaged when closing the lid.

<u>Note</u>: To avoid damage due to water, after de-rigging the water drain plug at the root rib forward edge should be removed (only valid up to S/N 8500) and discharge openings on wing under side kept open for ventilation (use valve openers provided).